

User Guide

Product Introduction

The sensor, with its stable performance and high sensitivity, is an important tool for observing and studying the occurrence, evolution and improvement of saline soils and water-salt dynamics. Measurement of the dielectric constant of the soil provides a direct and stable reflection of the true water content of various soils, as well as a measurement of the volume percentage of soil moisture.



Use Case Scenarios

The sensor is suitable for soil moisture monitoring, scientific experiments, water-saving irrigation, greenhouses, flowers and vegetables, meadows and pastures, rapid soil measurement, plant cultivation, wastewater treatment, fine agriculture and other occasions.

Features

- 1. Soil water content, conductivity and temperature in one.
- 2. Completely sealed, acid and alkali corrosion resistant, can be buried in the soil or directly into the water for long-term dynamic detection.
- 3. High precision, fast response, good interchangeability, probe insertion design ensures accurate measurement and reliable performance.

Specifications						
Model	UB-SEC-N1					
Power Supply	DC 4.5~30V					
Max Current	110mA (@5V)					
	EC: 0~20000µS/cm					
Measuring Range	Temperature: -40~80°C					
	Humidity: 0~100%					
	EC: ±3%FS (0~10000µS/cm), ±5%FS (10000~20000µS/cm)					
A	Temperature: ±0.5°C					
Accuracy	Humidity: ±2% (@0~50%, palm soil+30%+25°C) ; ±3% (@50~100%, palm					
	soil+60%+25°C)					
	EC: 1µS/cm					
Resolution	Temperature: 0.1°C					
	Humidity: 0.1%					
Protection level	IP68					
Connector	Audio					
Cable Length	3m					
Communication Protocol	RS485 Modbus RTU Protocol					
RS485 Address	0xD6					
Baud Rate	1200 bit/s,2400 bit/s, 4800 bit/s (default), 9600 bit/s, 19200 bit/s					

Product Specifications

Wiring Instruction



Measurement Area

Measurement area: Inside a 5cm diameter cylinder of equal height to the probes, centred on the centre of the two probes.



Quick Test Method

Select a suitable measurement site, avoid rocks and ensure that the steel needle does not touch hard objects. Throw away the top layer of soil according to the required measuring depth, keep the original tightness of the soil underneath, and insert the sensor vertically into the soil by holding it tightly. Do not shake the sensor from side to side when inserting it. It is recommended to take several measurements within a small area of one measurement point to find the average value.



Ground Penetration Method

Vertically dig a pit with a diameter of >20cm. Insert the sensor pin horizontally into the pit wall at the established depth and fill the pit tightly. After a period of stabilisation, measurements and recordings can be made over a period of days, months or even longer.



Communication protocols

1. Communication basic parameters

Communication Basic Parameter						
Coding System	8–bit binary					
Data Bit	8 bits					
Parity Checking Bit	none					
Stop Bit	1 bit					
Error Checking	CRC Check					
Baud Rate	1200 bit/s, 2400 bit/s, 4800 bit/s (default), 9600 bit/s, 19200 bit/s					

2. Data Frame Format

The Modbus-RTU communication protocol is used in the following format:

- Initial structure \geq 4 bytes in time.
- Address code: 1 byte, default 0xE1.
- Function code: 1 byte, support function code 0x03 (read only) and 0x06 (read/write).
- Data area: N bytes, 16-bit data, high byte comes first.
- Error check: 16-bit CRC code.
- End structure \geq 4 bytes of time.

Request											
Slave Addres	S	Function Cod		Register Address		No. of Registe	ers	CRC LSB		CRC MSB	
1 byte		1 byte	è	2	bytes	2 bytes		1 byte		1 byte	
Response											
Slave Address	Fur	inction Code No. of		f Bytes Content 1		Content 1		Conte		nt n	CRC
1 byte		1 byte	1 byte		2 bytes	2 bytes			2 byt	es	2 bytes

3. Register Address

Register Address									
Address (hex)	Content	Register Length	Function Code	Description of definitions					
0x0000	Humidity	1	03	Unsigned integer data, divided by 10					
0x0001	Temperature	1	03	Signed integer data, divided by 10					
0x0002	EC	1	03	Integer					
0x07D0	Address	1	03/06	1~255					

NOTE

- 1. The probe must be fully inserted into the soil when measuring.
- 2. Pay attention to the lightning protection when using in the field.
- 3. Do not violently bend the probe, do not pull the sensor lead wire, do not drop or hit the sensor violently.